

# baierBOARD

## STANDARD PLASTERBOARD FIXING SCHEDULE


### STEEL FRAME VERTICAL FIXING

#### RECOMMENDED OPTION

#### ALTERNATIVE OPTION

SCREW FIXING AT 200 mm CENTRES TO PERIMETER STUDS, 600mm CENTRES TO TOP AND BOTTOM PLATES

SCREW FIXING AT 300mm CENTRES TO INTERMEDIATE STUDS



SCREW FIXING AT 200 mm CENTRES TO PERIMETER STUDS, 600mm CENTRES TO TOP AND BOTTOM PLATES

DAUB OF ADHESIVE AT 600mm CENTRES AND SCREWS AT 600 mm CENTRES TO INTERMEDIATE STUDS

5 - 10mm GAP BETWEEN SHEET AND FLOOR

STUDS AT 600mm CENTRES MAXIMUM

### STEEL FRAME HORIZONTAL FIXING


#### RECOMMENDED OPTION

#### ALTERNATIVE OPTION

SCREW FIXING AT 200 mm CENTRES TO PERIMETER STUDS, 600mm CENTRES TO TOP AND BOTTOM PLATES

SINGLE SCREW TO EACH STUD WHERE SHEET CROSSES

SCREW FIXING AT 300mm CENTRES TO INTERMEDIATE STUDS



SCREW FIXING AT 200 mm CENTRES TO PERIMETER STUDS, 600mm CENTRES TO TOP AND BOTTOM PLATES

SINGLE SCREW TO EACH STUD WHERE SHEET CROSSES

DAUB OF ADHESIVE AT 600mm CENTRES AND SCREWS AT 600 mm CENTRES TO INTERMEDIATE STUDS

5 - 10mm GAP BETWEEN SHEET AND FLOOR

STUDS AT 600mm CENTRES MAXIMUM